

## 034Motorsport Billet Tow Hook



034Motorsport's Billet Tow Hook is the new standard in performance and durability. This tow hook was engineered with performance, and more importantly, strength, in mind. Manufactured from billet 4140 Chromoly Steel and 303 Stainless Steel, for strength and long lasting great looks.

## Installation Spiciness Rating



(Mild)

Installation of your 034Motorsport Billet Tow Hook is a straightforward process that will take approximately 3 minutes to complete.

### Supplied Parts:

- 034Motorsport Billet Tow Hook Kit

### Tools Needed:

- Wrench – 24mm (or adjustable wrench)
- Thumbs

## About This Guide

This Install Guide documents the installation process on a 2018 Audi RS3. Photos of the covers on additional vehicles are added for those installations. There may be minor differences in the shape of the tow hook socket cover, and which corner needs to be pressed in, or pried out, to remove it, depending on specific vehicle, market, options, etc.

## Getting Started

- Ensure you have all parts and tools required for installation by reading the complete Install Guide.

## Step 1

Press thumb into the corner of the tow hook socket cover:

**A3/S3/RS3/TT/TTS/TTRS** – Press in at top left corner



## Step 1 (cont.)

B9 A4/S4/A5/RS5 – Press in at bottom



B8 A4/S4/A5/S5/RS5 – Pry out top with fingernail or rigid card (credit card, driver's license, etc.)



## Step 2

Remove cover. Be careful not to break the tether.



## Step 3

Screw in tow hook assembly, and tighten shaft with 24mm wrench.



## Step 5

Adjust the tow hook loop so that it is orientated down, with the swing limiter also orientated down. Tighten the jamb nut.



## Step 6

Enjoy the Upgrade!

